

ETI Digital Technology's Site Preparation Guide

Customer Information:

Lab / Office Name: _____ Phone: _____

Lab / Office Address: _____ E-mail: _____

Customer Representative: _____

Systems:

DT3 Post Processing System

Purpose:

This guide provides the specifications and site requirements for the DT3 Post Processing System. This information should be used to plan the placement of and requirements for the DT3, as well as preparing for our service technician to install our equipment at your location (or remotely). Your site must meet the requirements outlined in this document before your system can be scheduled for installation. Failure to comply with these requirements and specifications may result in the customer incurring additional charges at ETI Digital Technology's discretion.

Assistance:

If you have any question or problems regarding the site preparation for any of your systems, we would be more than happy to help you.

Please contact us at:
(714) 238-1490 | support@etidigitaltechnology.com



Site Prep Check List:

Completion of the checklist below confirms that the critical aspects of site preparation, which are further detailed in the remainder of this document, have been addressed.

- Table/Counter that can bare 55kg/121lbs. Recommended table/counter high is 80cm, which brings the DT3 to height of 129cm.
- 30cm for maintenance around the DT3.
- Garden Hose 3/4 inch for the drain – should be provided by the customer.
- Suitable 3/4 inch drain for the waste per the local regulations.
- Power: 110- 120 VAC 50/60Hz, 2.3 Amps, CC 5Amp

Please obtain the following chemicals for use with your DT3:

- NaOH (CAS 1310-73-2) Sodium Hydroxide
- Na2SiO3 (CAS 6834-92-0) Sodium Metasilicate
- Glycerol (to improve material properties after long soaks in the cleaning station)
- Citric Acid (to neutralize the solution before draining)
- PH paper (to confirm the solution was neutralized)

Please read before Signing:

Customer Acknowledgment Signature below indicates that this document has been reviewed and the terms and conditions described throughout the document are accepted. Failure to comply with the site preparation guide may result in the customer incurring additional charges should the service technician be required to revisit the customer’s location. Additional charges are at the discretion of ETI Digital Technology. Please sign and return this page to ETI Digital Technology by Fax or E-mail prior to scheduling your installation.

Date

Customer Representative Signature

Date

ETI Digital Technology Representative Signature

ETI Digital Technology | (CAD/CAM Division of ETI Empire Direct)
955 N. Shepard Street | Anaheim, CA 92806 | Office: (714)-238-1490 Fax: (714)-238-9126
www.etidigitaltechnology.com | E-mail: support@etidigitaltechnology.com

